



# ASSEMBLY INSTRUCTION

## Kit Contents:-

1. Bolts-5pc.  
20x8mm



2. Washer-5pc.  
8mm



3. Spanner-1pc.  
12-13no.



## Instructions:-

1. Place the cabinet & leg on a protective surface.
2. Match the base holes and cabinet bottom holes. (see image 2)
3. Fix with bolts & washers using with spanner. repeat same for other end.(see image 3)
4. Cabinet can be turned upright and is ready to use.(see image 4)

